Instrument Panel

Windshield wiper and washer switch P.39
Power (ignition) switch P.26
A
See P.5.
C
Trunk opener main switch P.76
CLYFQ0H169
See P.7.
Transmission shift lever P.27
Parking brake switches P.30

Overview

Instrument Panel

B
Without LKA (Lane-Keeping Assist)
Distance switch * P.34
"DISP" switch P.32
Talk switch P.66
Telephone switch P.52
Brake hold switch P.31
Cruise control switch P.33, 34
With LKA (Lane-Keeping Assist)
"DISP" switch P.32
Talk switch P.66
Telephone switch P.52
Brake hold switch P.31
Cruise control switch P.33, 34
Distance switch * P.34

*: If equipped

C
Without rear console display
Rear seat return switch * P.20
Rear sunshade switch P.67
Rear door sunshade switch * P.67
Driving mode selector switch P.28
CLYFQ0H166
With rear console display
Rear seat return switch P.20
Rear sunshade switch P.67
Front passenger's power seat switches P.18
Rear door sunshade switch P.67
Driving mode selector switch P.28
CLYFQ0H166
* : If equipped

Rear Armrest (5-seat models)

▶ Without relaxation seat

Power seat switches * P.20

Rear air conditioning switches * P.65

Rear sunshade switch P.67

Rear door sunshade switches * P.67

▶ With relaxation seat

Power seat switches P.20

Rear air conditioning switches P.65

Rear sunshade switch P.67

Rear door sunshade switches P.67

* : If equipped

Rear Armrest (4-seat models)

Rear air conditioning switches P.65

Rear sunshade switch P.67

Rear door sunshade switches P.67

Power seat switches P.20